

# Strain-Bridge Converter DMS 1000

**Weight - Force - Pressure - Torque with DMS Strain-Bridges**

## Features

- 1- or 2 way action, e.g. force or force/traction programmable
- Teach-in function
- Front side LCD-Display with backlighting
- Programming via front keypad
- Tare-function (internal / external) and simulation mode
- Integrated bridge-supply 2.5 V/5 V/10 V
- Resolution 16 Bit
- Accuracy <0.05 % ±2 digit
- Analog output 0/4 ... 20 mA; 0 ... 10V DC
- 1 Alarm output, relay SPDT
- Wall- and DIN-rail TS35 mounting



## General

The DMS1000 converts small signal output of any common strain bridges (load cells) into a standard signal 0/4...20 mA, 0...10 V DC. Bridge supply and an input for tare fade-out is included. If an application needs more than one load cell they must be parallel connected. If the max bridge current would be more than 50 mA, it is necessary to connect a strain bridge booster SBB1616 between load cells and DMS1000.

## Short information

Programming	The device will be programmed via front-side membrane keypad in connection with integrated LCD-Display.
Teach-in function	When operating with two reference weights, the DMS1000 can calculate the bridge-sensitivity of an installed load cell, respectively the arithmetic average value of the sensitivity, if several load cells are installed.
Tare-function	The displayed value can be set to " 0 " by keypads or external control signal.
Alarm output	Switching performance for the alarm output is programmable as minimum or maximum function. The status of the output will be displayed.
Analog output	DMS1000 offers an analog output signal 0/4 ... 20 mA or 0 ... 10 V DC proportional to the mechanical load within the programmed measuring range.
Sense input	The sense input is used to compensate the line resistance between DMS strain-bridge (load cell) and DMS1000.

## Technical data

### Power supply

Supply voltage	: 230 V AC $\pm 10$ %; 115 V AC $\pm 10$ %; 24 V AC $\pm 10$ % or 24 V DC $\pm 15$ %
Power consumption	: max. 3.5 VA
Working temperature	: -10 ... +55 °C (14 ... 131 °F)
Rated voltage	: 250 V~ acc. to DIN VDE 0110 between, input, analog output/relay output/ supply voltage, Degree of pollution 2, over-voltage category III
Test voltage	: 4kV=, between input, analog output/relay output/supply voltage
CE - conformity	: EN55022, EN60555, IEC61000-4-3/4/5/11/13

### Input

Bridge supply	: 2.5/5/10 V DC ; programmable; max. 50 mA
Bridge sensitivity	: 0.4/0.2/0.1 ... 5.00 mV/V
Sense connection	: Line resistance about max. 10 $\Omega$ is compensated
Accuracy	: < 0.05 % $\pm 2$ Digit
Temperature coefficient	: 0.005 %/K
Display	: LCD Dot-Matrix 2 lines 8 characters each, character height 5 mm, backlighting
Display range	: $\pm 9999(0)$ digit with leading zero suppression


### Output

Relay	: SPDT <250 V AC <250 VA <5 A, <300 V DC <50 W <2 A
Analog output	: 0/4 ... 20 mA burden $\leq 500 \Omega$ or 0 ... 10 V load max 5 mA, programmable (not isolated to the measuring input)
-Accuracy	: 0.1 %; TK 0.01 %/K

### Case


Case	: Standard case Polycarbonate 8020 UL 94V-1, DIN-rail TS35 mounting, or wall mounting
Dimensions	: 55x75 mm(WxH) mounting depth 110 mm
Weight	: max. 390 g
Connection	: Screw terminals, max. 4 mm <sup>2</sup>
Protection	: Case IP40, terminals IP20, finger safe acc. to German BGV A3

## Abmessungen




Wall-mounting with 2 screws M4 acc. to DIN46121 / DIN 43660  
or DIN-rail mounting TS35 acc. to DIN 46277 and DIN EN 50022




## Connection diagrams







## Controls and indicators




## Description


Operation of the device is arranged in 2 levels. While programming, pressing button  saves the current parameter and moves to the next programming step. For selection within a parameter or for entering data, use buttons  and .

Button combinations:

-  +  one parameter back.
-  +  setting parameter to zero or minimum value.

After powering up, the device initializes itself. The display shows the message DMS1000 and software version. After the initialization the device is located in the **Working level**. The set point of the alarm output can be adjusted and min- and max. values can be called.

Pressing the button  for more than 2 seconds, activates the **Configuration level**. Now all the parameters which defines the function of the converter can be programmed.

After finishing the configuration or when no button was pushed for more than 2 minutes, the program returns to the working level and the display shows the process value. Leaving the configuration level is possible at any time by pushing the button  for 2 seconds.

## Error messages:

- Display flashes If the input signal leaves the programmed range.
- P-ERROR Factory calibration is necessary
- P-lock Programming lock. See configuration page 7, parameter 23

## Installation note!

Before the device can be used, it must be configured for the intended use.

⇒ see page 5

## Notes to representation



Parameter is only displayed if configured











































Parameter is only displayed if included (see order code)

**Note:** All parameters can be called if they are not blocked by other programmed parameters and if they are available. Factory settings are shown in the **display graphic**.

## Working level

Button	Display	Description
		Process-value Indication of alarm output (only if activated). □ = OFF and ■ = ON
		Display max. value Reset with button , or at every power off.
		Display min. value Reset with button , or at every power off.
		Tare-function Pressing button  for more than 3 s , the display will be reset to "0".
		Display conversion, <b>option 11</b> Setting possible from $\times 0,10$ ... $\times 10,00$ with buttons  und .
		Setpoint alarm output Setting possible in the programmed measuring range with buttons  und .

## Configuration

Button	Display	Description (displayed values are factory settings)
 press 2s 	1 	<b>Configuration level</b> Language of the operating instructions Selection with buttons  and  .
 	2 	Digital filter. Averaging of the measured values over the programmed time [s]. OFF, 0.1, 1.5, 10, 20, 40s Selection with buttons  and  .
 	3 	Display unit kg, t, N, kN, bar Selection with buttons  and  .
 	4 	Fixed zero 0, e.g. 2500+0. Selection with buttons  and  .
 	5 	Decimal point position 0000; 000,0; 00,00; 0,000 Selection with buttons  and  .
 	6 	Measuring unit of the strain bridge (load cell) kg, t, N, kN, bar Selection with button  and  .
 	7 	Nominal load of the strain bridge (load cell) Setting possible from 1 ... 9999 Digit with buttons  and  . If the load is distributed to several identic cells, the summation of the nominal load has to be entered.
 	8 	Bridge supply 2.5V, 5V, 10V DC Selection with buttons  and  .

continue  
page 6

Button	Display	Description (displayed values are factory settings)
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           9            Teach In?  <input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON         </div>	Teach-in function. Adjustment of the strain-bridge with reference weights to determine the bridge-sensitivity [mV/V]. Selection with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px dashed black; padding: 5px; width: fit-content;">           10            m1            kg                             0         </div>	1. calibration point Setting possible in range of the programmed nominal load with buttons ▲ and ▼. This parameter will not be left automatically after 120 seconds.
↺		
↓	<div style="border: 1px dashed black; padding: 5px; width: fit-content;">           11            m2            kg                             100         </div>	2. calibration point The difference to the 1. calibration point must be at least 10% of the programmed nominal load. Setting possible with buttons ▲ and ▼. This parameter will not be left automatically after 120 seconds.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           12            DMS mV/V                      2.000         </div>	Bridge-sensitivity [mV/V] Setting possible from 0.100 ... 5.000 mV/V with buttons ▲ and ▼. If the load is distributed to several identic cells, the arithmetic average value of the bridge sensitivity has to be entered.
↺		Note: When the teach-in function is accomplished, the calculated value of the sensitivity will be displayed. If this value is out of range, an error message occurs and the value will not be stored.
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           13            Direct            ▼ 1-dir         </div>	Direction of action. 1-dir = 0 ... measuring range; or 2-dir = 0 ... ± measuring range. Selection with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           14            Output            ▼ 0-20mA         </div>	Analog output 0 - 20, 4 - 20 mA or 0-10V Selection with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           15            MR Start                      0kg         </div>	Start value for measuring range and analog output Setting possible from 0 (-9999) ... 9999 digit with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           16            MR End                  1000kg         </div>	End value for measuring range and analog output Setting possible from -9999 ... 9999 digit with buttons ▲ and ▼. Note: If MR Start > MR End, the output works with a decreasing characteristic
↺		

continue  
page 7

Button	Display	Description (displayed values are factory settings)
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           17            Alarm            ▼ OFF         </div>	Switching performance alarm output OFF, MIN, MAX Selection with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px dashed black; padding: 5px; width: fit-content;">           18            Setpoint            0         </div>	Setpoint alarm output Setting possible within the programmed measuring range with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px dashed black; padding: 5px; width: fit-content;">           19            Hyst.            1         </div>	Hysteresis alarm output Setting possible within the programmed measuring range with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           20            Simul.            1850kg         </div>	Simulation of the load-cell The DMS1000 works as a simulator. The analog output changes within the programmed measuring range. Setting possible with the buttons ▲ and ▼. Please note: This parameter will not be left automatically after 120 seconds.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           21            Corr.AO            0.000mA         </div>	Correction start value analog output Setting possible ±2 mA or ±1 V with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           22            Corr.AO            20.000mA         </div>	Correction end value analog output Setting possible ±2 mA or ±1 V with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           23            P-Lock            ▼ OFF         </div>	Parameter lock OFF : no lockout CONF IG : configuration level locked ALL : all parameters locked Selection with buttons ▲ and ▼.
↺		
↓	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           24            FactCode            0         </div>	Code for factory settings
↺		
	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           450            AL■ kg         </div>	Back to the working level

## Ordering code

DMS1000 -  1. -  2. -  3. -  4. -  5. -  6.

### 1. Model

- 1 Input Strain-Bridge (DMS-load cell),  
integrated bridge-supply 2.5/5/10 V DC max. 50 mA,  
input for extern tare function with voltage free contact
- 2 as before, but extern tare function with 24 V DC signal  
intern isolated by opto-coupler

### 2. Alarm output

1R 1 Alarm output Relay SPDT

### 3. Analog output

AO Analog output 0/4 ... 20 mA or 0/2 ... 10 V DC  
not isolated to the measuring input

### 4. Supply voltage

0	230 V AC	± 10 %	50-60 Hz
1	115 V AC	± 10 %	50-60 Hz
4	24 V AC	± 10 %	50-60 Hz
5	24 V DC	± 15 %	

### 5. Option

00	Without option
11	Display conversion from x0,10 ... x10,00

### 6. Additional text (appears on the face plate in the field additional text, maximum 3mm x 50mm wxH )